TECHNICAL DATA SHEET



QUICK DRY SATIN

A water based satin sheen coating designed to be applied over correctly primed interior wood and metal surfaces. A quick drying and low odour alternative to traditional satin, it offers a long lasting, non-yellowing finish.

AVAILABILITY		
Colour	White	
Packaging	1L and 2.5L	
PROPERTIES		
Suitable Surfaces	Suitably prepared interior wood and metal surfaces	
Drying Time @ 20*C/65%RH	Under normal drying conditions touch dry in 1 hour and recoat after 4 hours. Allow for	
	adequate ventilation during the drying period.	
Finish	Satin	
Composition	Pigment: Titanium Dioxide and extenders	
	Binder: Resin: Acrylic polymer	
	Solvent: Water	
Spreading Rate	Up to 14m² per litre on smooth surfaces	
Wet Film Thickness	70 micrometres at 14m² per litre	
Dry Film Thickness	24 micrometres at 14m² per litre.	
Volume Solids	34%.	
Flash Point	Not applicable	
VOC Content	EU limit value for this product (cat.A/d): 130 g/l (2010). This product contains max. 2 g/l VOC.	
Limitations	Do not apply when air or substrate temperatures are likely to fall below 8°C or when the	
	relative humidity is above 80% during application or the drying period. Do not over apply.	
PREPARATION		
All New Metals	Lightly abrade to a bright (not polished) surface, excluding galvanised surfaces. Wash with	
	hot water and liquid detergent solution to remove oil, grease or any other contaminants,	
	frequently changing the water. Rinse thoroughly with clean water. Allow to dry. When dry	
	prime with one coat of Crown Contract All Purpose Primer followed by one coat of Crown	
	Contract Quick Dry Primer Undercoat.	
Galvanised Metal	Bright galvanised surfaces should be thoroughly degreased as per new metals, then pre-	
	treated with a T Wash. Overall blackening of the surface will confirm satisfactory surface	
	degreasing. When dry prime with one coat of Crown Contract All Purpose Primer followed	
	by one coat of Crown Contract Quick Dry Primer Undercoat.	
Non Ferrous Metals	Prime bare metal with one coat of Crown Contract All Purpose Primer followed by one	
	coat of Crown Contract Quick Dry Primer Undercoat.	



TECHNICAL DATA SHEET



Ferrous Metals	Remove all millscale and surface rust back to clean bright metal. Remove all residues. Prime
	within the working day with one coat of Crown Contract All Purpose Primer followed by
	one coat of Crown Contract Quick Dry Primer Undercoat.
Previously Decorated Metal	All surfaces must be suitably dry, and free from anything that will interfere with the adhesion
Surfaces	of the materials to be applied. Remove all loose and failing or suspect paint. Organic growth
	must be treated with Sandtex Trade Fungicidal Solution and removed. Feather edges of
	sound paint. Remove all dust. Remove all rust. Spot prime all bare metalwork with Crown
	Contract All Purpose Primer. Wash remaining sound paint with hot water and liquid
	detergent solution to remove any contaminants, frequently changing the water. Wet abrade to
	provide a key. Rinse with clean water to remove all residues. Allow to dry. Bring forward spot
	primed areas with one coat of Crown Contract Quick Dry Primer Undercoat.
New Wood Surfaces	All surfaces must be sound, clean, suitably dry and free from anything that will interfere with
	the adhesion of the materials to be applied. Rub down with a suitable grade of abrasive
	paper and round sharp edges to a 1-3mm radius. Remove all dust. Timber with
	oils/extractives must be swabbed with clean methylated spirits, frequently changing the face
	of the cloths. Treat any knots with two coats of fresh knotting. Fill any fixing holes, open joints
	and shallow surface defects with Sandtex Ready Mixed Filler or 2 pack wood filler. Prior to
	priming the mainture content of the substrate abould not exceed 100/ Apply one cost of
	priming the moisture content of the substrate should not exceed 18% Apply one coat of
	Crown Contract Quick Dry Primer Undercoat.
Previously Decorated Wood	
Previously Decorated Wood Surfaces	Crown Contract Quick Dry Primer Undercoat.
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint.
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges of sound paint. Remove all dust. Organic growth must be treated with Sandtex Trade
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges of sound paint. Remove all dust. Organic growth must be treated with Sandtex Trade Fungicidal Solution and removed. Remove any defective putty glazing, clean and prime
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges of sound paint. Remove all dust. Organic growth must be treated with Sandtex Trade Fungicidal Solution and removed. Remove any defective putty glazing, clean and prime rebates, replacement putties must be allowed to form a hard skin. Treat knots with two thin
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges of sound paint. Remove all dust. Organic growth must be treated with Sandtex Trade Fungicidal Solution and removed. Remove any defective putty glazing, clean and prime rebates, replacement putties must be allowed to form a hard skin. Treat knots with two thin coats of fresh knotting. Fill any fixing holes, cracks and shallow surface defects with Sandtex
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges of sound paint. Remove all dust. Organic growth must be treated with Sandtex Trade Fungicidal Solution and removed. Remove any defective putty glazing, clean and prime rebates, replacement putties must be allowed to form a hard skin. Treat knots with two thin coats of fresh knotting. Fill any fixing holes, cracks and shallow surface defects with Sandtex Ready Mixed Filler or 2 pack wood filler. Wash remaining sound paint with hot water and
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges of sound paint. Remove all dust. Organic growth must be treated with Sandtex Trade Fungicidal Solution and removed. Remove any defective putty glazing, clean and prime rebates, replacement putties must be allowed to form a hard skin. Treat knots with two thin coats of fresh knotting. Fill any fixing holes, cracks and shallow surface defects with Sandtex Ready Mixed Filler or 2 pack wood filler. Wash remaining sound paint with hot water and liquid detergent solution to remove any contaminants, frequently changing the water. Wet
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges of sound paint. Remove all dust. Organic growth must be treated with Sandtex Trade Fungicidal Solution and removed. Remove any defective putty glazing, clean and prime rebates, replacement putties must be allowed to form a hard skin. Treat knots with two thin coats of fresh knotting. Fill any fixing holes, cracks and shallow surface defects with Sandtex Ready Mixed Filler or 2 pack wood filler. Wash remaining sound paint with hot water and liquid detergent solution to remove any contaminants, frequently changing the water. Wet abrade to provide a key. Rinse with clean water to remove all residues. Allow to dry. Prior to
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges of sound paint. Remove all dust. Organic growth must be treated with Sandtex Trade Fungicidal Solution and removed. Remove any defective putty glazing, clean and prime rebates, replacement putties must be allowed to form a hard skin. Treat knots with two thin coats of fresh knotting. Fill any fixing holes, cracks and shallow surface defects with Sandtex Ready Mixed Filler or 2 pack wood filler. Wash remaining sound paint with hot water and liquid detergent solution to remove any contaminants, frequently changing the water. Wet abrade to provide a key. Rinse with clean water to remove all residues. Allow to dry. Prior to priming the moisture content of the substrate should not exceed 18% Spot prime bare and
-	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges of sound paint. Remove all dust. Organic growth must be treated with Sandtex Trade Fungicidal Solution and removed. Remove any defective putty glazing, clean and prime rebates, replacement putties must be allowed to form a hard skin. Treat knots with two thin coats of fresh knotting. Fill any fixing holes, cracks and shallow surface defects with Sandtex Ready Mixed Filler or 2 pack wood filler. Wash remaining sound paint with hot water and liquid detergent solution to remove any contaminants, frequently changing the water. Wet abrade to provide a key. Rinse with clean water to remove all residues. Allow to dry. Prior to priming the moisture content of the substrate should not exceed 18% Spot prime bare and filled areas with one coat of Crown Contract Quick Dry Primer Undercoat followed by one
Surfaces	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges of sound paint. Remove all dust. Organic growth must be treated with Sandtex Trade Fungicidal Solution and removed. Remove any defective putty glazing, clean and prime rebates, replacement putties must be allowed to form a hard skin. Treat knots with two thin coats of fresh knotting. Fill any fixing holes, cracks and shallow surface defects with Sandtex Ready Mixed Filler or 2 pack wood filler. Wash remaining sound paint with hot water and liquid detergent solution to remove any contaminants, frequently changing the water. Wet abrade to provide a key. Rinse with clean water to remove all residues. Allow to dry. Prior to priming the moisture content of the substrate should not exceed 18% Spot prime bare and filled areas with one coat of Crown Contract Quick Dry Primer Undercoat followed by one coat of Crown Contract Quick Dry Primer Undercoat
Surfaces	Crown Contract Quick Dry Primer Undercoat. All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose, failing or suspect paint. Remove grey and denatured surfaces by rubbing down with abrasive paper. Feather edges of sound paint. Remove all dust. Organic growth must be treated with Sandtex Trade Fungicidal Solution and removed. Remove any defective putty glazing, clean and prime rebates, replacement putties must be allowed to form a hard skin. Treat knots with two thin coats of fresh knotting. Fill any fixing holes, cracks and shallow surface defects with Sandtex Ready Mixed Filler or 2 pack wood filler. Wash remaining sound paint with hot water and liquid detergent solution to remove any contaminants, frequently changing the water. Wet abrade to provide a key. Rinse with clean water to remove all residues. Allow to dry. Prior to priming the moisture content of the substrate should not exceed 18% Spot prime bare and filled areas with one coat of Crown Contract Quick Dry Primer Undercoat followed by one coat of Crown Contract Quick Dry Primer Undercoat Apply two coats.



TECHNICAL DATA SHEET



	short/medium pile roller. Maintain a wet edge.
	Always intermix (box) packs for colour consistency. Please check for colour accuracy prior to
	application. Crown Paints is not liable for decorating costs caused as a result of an incorrect
	colour being applied.
CLEANING	Return surplus material to container. Wash tools & equipment with clean water or warm
	soapy solution and rinse immediately after use.
STORAGE	Store upright and secure. Store in secure dry conditions inaccessible to children or animals.
	Containers should be kept closed during storage. Do not store below 5°C or above 40°C.
MAINTENANCE	Between maintenance redecoration, surfaces may be washed with a warm water and liquid
INFORMATION	detergent solution to remove surface dirt.
HEALTH AND SAFETY	Please refer to the Safety, Health and Environmental Information on the container. Take
	special precautions during the surface preparation of pre 1960's painted surfaces as they
	may contain harmful lead. For further information contact the Customer Relations Team.
	When preparing all surfaces avoid the inhalation of dust and/or metal particles. Wear a
	suitable facemask. Material Safety Data Sheets for this and all other Crown Paints products
	are freely available from the place of purchase or the address below. Do not empty into
	drains, watercourses or access routes to septic tanks.
GENERAL INFORMATION	Apply all products in accordance with BS 6150: Code of practice for painting of buildings and
	BS 8000: Part 12: Code of practice for decorative wallcoverings and painting.
	Every care is taken to ensure that all information provided on this Technical Data Sheet is
	accurate. Crown Paints is unable to guarantee results as it has no control over the conditions
	under which its products are applied.
	Before using this product, please ensure you have the latest information. For help or more
	information contact the Crown Contract Customer Relations Team on:
	Tel: 0330 0240281
	Fax: 0330 0240278
	e-mail: info@crowncontract.co.uk
	website: www.crowncontract.co.uk
	This information is correct at date of issue November 2021.

